

MAINTENANCE OF A100 & A500 ALLOY “FITZROY” SLIDING DOOR TRACKS

To keep “Fitzroy” tracks running smoothly and easily, inspect every 2 – 5 years. Apply grease sparingly to the ball bearings as required

If the door does not move smoothly and easily, look for the following:

- Door dragging on the floor or wall
- Door binding on the guide
- Fixings of “Fitzroy” track to wall or overhead beam is loose or insufficient
- Fixing of the “Fitzroy” track to the door